

Two-axis Analog Joystick Interface, JOYSTK-2- 01

25-pin DB-25, Male Connector, Cable Length = 5.5 ft (168 cm)

Slide the knobs to the opposite side to engage / disengage the joystick.

PIN	NAME	DESCRIPTION
1	ANALOG-X	Analog-X, Wiper of 5 KOhm Potentiometer
2	ANALOG-Y	Analog-Y, Wiper of 5 KOhm Potentiometer
3	HIGH-SPEED	Upper Right Hand Switch, Normally Open
4	MEDIUM-SPEED	Middle Right Hand Switch, Normally Open
5	LOW-SPEED	Lower Right Hand Switch, Normally Open
6	SPARE	Lower Left Hand Switch, Normally Open
7		Not Connected
8		Not Connected
9		Not Connected
10		Not Connected
11		Not Connected
12		Not Connected
13		Not Connected
14		Not Connected
15		Not Connected
16	GND	System Ground
17	GND	System Ground
18	GND	System Ground
19	+5 VDC	+5 VDC
20	+5 VDC	+5 VDC
21	+5 VDC	+5 VDC
22		Not Connected
23		Not Connected
24		Not Connected
25		Not Connected



Moticont
6901 Woodley Avenue
Van Nuys, California 91406 U.S.A.
www.moticont.com

+1 (818) 785-1800
FAX +1 (818) 785-5713
E-mail moticont@moticont.com